


15. PARTS LIST



ITEM NO.	PART NO.	DESCRIPTION
1	RCS-1000	ASSY FRONT CABINET
2	RCS-3000	ASSY REAR CABINET
3	RCS-0001	INST HOLDER
4	RCS-0002	DENOMI PLATE
5	421-7907~	DENOMI SH 1 GAME~
6	422-10041X-01	PLAY INSTR SH RCS ENG
21	RCS-0005	TOP COVER PLATE
22	RCR-0018	LEG RUBBER