


ASSY START SW (RCS-3420)



ITEM NO.	PART NO.	DESCRIPTION
1	RCS-3421-01	SW BASE EXP
2	220-5232-03	COIN ENTRY
101	509-5892-01	SW PB 60M W/L 6V3W YELLOW