

TABLE OF CONTENTS

| | |
|--|-------|
| INTRODUCTION OF THE OWNERS MANUAL | 1 |
| GENERAL PRECAUTIONS | 2~3 |
| 1. PRECAUTIONS TO BE HEDED FOR OPERATION | 4 |
| 2. NAME OF PARTS | 5 |
| 3. ACCESSORIES | 6 |
| 4. ASSEMBLY AND INSTALLATION | 7~11 |
| 5. PRECAUTIONS TO BE HEDED WHEN MOVING MACHINE | 12 |
| 6. EXPLANATION OF TEST AND DATA DISPLAY | 13~20 |
| 6-1 COIN METER SWITCH UNIT | 14 |
| 6-2 TEST MODE | 15 |
| 6-3 GAME TEST MODE | 15 |
| 6-4 INPUT TEST | 16 |
| 6-5 SOUND TEST | 16 |
| 6-6 GAME ASSIGNMENTS | 17 |
| 6-7 VOLUME SETTING | 18 |
| 6-8 BOOKKEEPING | 19~20 |
| 6-9 BACKUP DATA CLEAR | 20 |
| 7. COIN SELECTOR | 21~23 |
| 8. MONITOR | 24~26 |
| 8-1 CAUTIONS CONCERNING SAFE HANDLING OF MONITOR | 24~25 |
| 8-2 CLEANING THE CRT SURFACES | 25 |
| 8-3 ADJUSTMENT METHOD | 26 |
| 9. REPLACEMENT OF FLUORESCENT LAMP | 27 |
| 9-1 REPLACEMENT OF FLUORESCENT LAMP | 27 |
| 10. PERIODIC INSPECTION TABLE | 28 |
| 11. TROUBLESHOOTING | 29 |
| 12. CONTROL PANEL/BAT MECHA | 30~31 |
| 13. GAME BOARD | 30 |
| 13-1 REMOVING THE GAME BOARD | 31 |
| 13-2 COMPOSITION OF THE GAME BOARD | 32 |
| 14. DESIGN RELATED PARTS | 33~44 |
| 15. PARTS LIST | XXX |
| 16. WIRING DIAGRAMS | |