

Field Service Bulletin

House of the Dead III Upright and Deluxe Models

Problem: The screws on the plastic covers of the slide mechanism can come loose during heavy usage. This can cause the covers to break or fall off.

Solution: Remove the 4ea Phillips screws, clean and re-install using Blue Loctite (242) on the threads. Tighten the screws. Be sure to be careful and not get the Loctite on the plastics parts as it can damage them.



Use Loctite on these screws
(4ea / 2ea per side)